

# NEW RAGE CYCLES

## INSTALLATION INSTRUCTIONS

### ALTA ENDURO/SUPERMOTO

#### FRONT TURN SIGNALS

- 1 Remove stock screws to take off stock blinkers (picture 1)
- 2 Unplug stock connector(s)
- 3 Take NRC blinker and unscrew lower lens bracket; use stock bolt and mount onto bike (picture 2)
- 4 Screw lens back onto lower bracket (picture 3)
- 5 Plug connectors in
- 6 Zip tie wires as needed
- 7 **Product comes with 22ohm resistor. Wiring instructions are on bag.**

