

# NEW RAGE CYCLES

## INSTALLATION INSTRUCTIONS

### HONDA CBR1000RR

#### FRONT TURN SIGNALS 2017-PRESENT

- 1 Remove (2) fairing screws on each side with a 3mm allen key to remove the stock windshield. (Picture 1)
- 2 Unplug OEM connectors if you will be removing the stock mirrors. (Picture 2)
- 3 Remove (2) fairing screws with a 3mm allen key on each side to mount new turn signals. (Picture 3)
- 4 Slide new turn signal bracket through fairing and reuse screws removed in prior step. (Picture 4)
- 5 Run wires to plugs behind windshield and splice in. The green wire / connector is the ground, and the brown wire / connector is positive.

#### If removing the stock mirrors and installing block off plates:

- 1 Remove (2) acorn nuts behind mirrors on each side. (Picture 5)
- 2 Take NRC block off plates, supplied M6 bolts, spacers and nuts and mount onto the bike. (Picture 6)

