

NEW RAGE CYCLES

INSTALLATION INSTRUCTIONS

YAMAHA R1

MIRROR BLOCK OFF TURN SIGNALS

- 1 Remove push pin and allen bolt.
- 2 Remove mirrors by unbolting acorn nuts with a 10mm socket on backside.
- 3 Unplug OEM connector and remove mirror.
- 4 To mount NRC signals, slide connector through single hole; line up 2 mounting holes and use provided M5 bolts and locking nuts to secure.
- 5 Plug in connector and zip tie if necessary.
- 6 Reinstall plastic panel previously removed.